



Key No.	Part No.	Part Name	Key No.	Part No.	Part Name
1	5K177623	PALM SIDE COVER	41	5K177133	GEAR SIDE COVER ASSEMBLY
2	5K134801	LOCK PIN	42	6K904901	O-RING
3	6K974402	COIL SPRING	43	5K027001	WASHER
4	5K207902	SPOOL COVER ASSEMBLY	44	6K176905	COLLAR
5	6AK21802	SCREW	45	6K177001	WASHER
6	5K027001	WASHER	46	5K207706	TENSION KNOB
7	6K474506	BALL BEARING	47	6K311307	SCREW
8	6K468301	RING	48	6K170604	BALL BEARING
9	5K295705	SPOOL ASSEMBLY (1 BALL BEARING)	49	63201402	RETAINER
10	6K704403	NUT	50	5K134901	BEARING PLATE
11	6K148801	WASHER	51	6E096501	WASHER
12	6K256501	LEVEL WIND PIN	52	6K398604	SCREW
13	63205901	RETAINER	53	5K093609	GEAR METAL
14	5K028501	BUSH	54	6K258101	GEAR
15	5K238001	LEVEL WIND ASSEMBLY	55	6K893602	RATCHET
16	6K626404	BALL BEARING	56	6K174504	WASHER
17	6K468601	PIPE	57	5K189304	DRIVE GEAR
18	5K093201	WORM SHAFT	58	5K190402	WASHER-L
19	5K028501	BUSH	59	6K943101	WASHER-D
20	6K164402	WASHER	60	5K094003	WASHER-L
21	6K469301	WORM PINION	61	5K094101	WASHER-A
22	6B339801	RETAINER	62	6K943103	WASHER-D
23	5K177312	HOOD	63	6K896716	SLEEVE
24	5K155601	SCREW	64	6K177301	WASHER
25	6K930403	PILLAR	65	6K177302	WASHER
26	6K311307	SCREW	66	6K259201	LEAF SPRING ASSEMBLY
27	6K311315	SCREW	67	5K027201	SPRING WASHER
28	5K181125	FRAME ASSEMBLY	68	6K193601	WASHER
29	5K138306	THUMB BAR ASSEMBLY	69	5K240520	STAR DRAG ASSEMBLY
30	5K138201	SPRING	70	5K199101	WASHER
31	5K177502	KICK LEVER	71	5K255703	HANDLE ARM ASSEMBLY
32	5K138401	SPRING	72	6K626401	BALL BEARING (4 BALL BEARING)
33	5K177401	CLUTCH CAM	73	5K129201	WASHER
34	6K723502	SCREW	74	5K316801	HANDLE KNOB ASSEMBLY
35	6K723502	SCREW	75	6K325306	SCREW
36	5K133401	CLUTCH	76	5K148820	HANDLE KNOB CAP
37	6K942501	COIL SPRING	77	5K199201	WASHER
38	5K130902	PINION	78	5K181808	NUT
39	6K170701	RING	79	5K005011	RETAINER
40	6K304004	BALL BEARING	80	63520407	SCREW