


KEY NO	PARTS NAME
No.1	Palm Side Cover
No.2	Click Pin
No.3	Click Spring
No.4	Coil Spring
No.5	Locking Dial
No.6	Control Dial Support
No.7	Screw
No.8	Control Dial
No.9	Coil Spring
No.10	Pin
No.11	O-Ring
No.12	Lock Lever
No.13	Tap Screw
No.14	Slide Cam
No.15	Coil Spring
No.16	Spool Cover
No.17	Tap Screw
No.18	Tap Screw
No.19	Magnet Holder ASSY
No.20	Washer
No.21	Ball Bearing
No.22	Ring
No.23	Spool ASSY(One Ball Bearing)
No.24	Tap Screw
No.25	Tap Screw
No.26	Tap Screw
No.27	Front Support
No.28	Retainer
No.29	Frame
No.30	Tap Screw

KEY NO	PARTS NAME
No.31	Thumb Bar
No.32	Retainer
No.33	Bush
No.34	Level Wind ASSY
No.35	Level Wind Pin
No.36	Washer
No.37	Nut
No.38	Pipe
No.39	Worm Shaft
No.40	Washer
No.41	Worm Pinion
No.42	Retainer
No.43	Spring
No.44	Kick Lever
No.45	Spring
No.46	Clutch Cam
No.47	Tap Screw
No.48	Clutch
No.49	Coil Spring
No.50	Pinion
No.51	Gear Side Cover ASSY
No.52	Tap Screw
No.53	O-Ring
No.54	Bearing
No.55	Washer
No.56	Washer
No.57	Tension Knob
No.58	Ball Bearing
No.59	Retainer
No.60	Bearing Plate

KEY NO	PARTS NAME
No.61	
No.62	Screw
No.63	Gear Metal
No.64	Gear
No.65	Ratchet
No.66	Washer
No.67	Drive Gear
No.68	Washer-L
No.69	Washer-D
No.70	Washer-A
No.71	Bush(Sleeve)
No.72	One Way Clutch ASSY
No.73	Ball Bearing
No.74	Washer
No.75	Leaf Spring ASSY
No.76	Spring Washer
No.77	Star Drag
No.78	Washer
No.79	Handle ASSY
No.80	Handle Nut Cap
No.81	Screw
No.82	Nut
No.83	Collar
No.84	Washer-D
No.85	O-Ring
No.86	Handle Knob Cap
①	P/SIDE COVER ASSY
②	Tension Knob ASSY
③	Handle ASSY + Knob Cap



KEY NO	PARTS NAME
No.1	Palm Side Cover
No.2	Click Pin
No.3	Click Spring
No.4	Coil Spring
No.5	Locking Dial
No.6	Control Dial Support
No.7	Screw
No.8	Control Dial
No.9	Coil Spring
No.10	Pin
No.11	O-Ring
No.12	Lock Lever
No.13	Tap Screw
No.14	Slide Cam
No.15	Coil Spring
No.16	Spool Cover
No.17	Tap Screw
No.18	Tap Screw
No.19	Magnet Holder ASSY
No.20	Washer
No.21	Ball Bearing
No.22	Ring
No.23	Spool ASSY(One Ball Bearing)
No.24	Tap Screw
No.25	Tap Screw
No.26	Tap Screw
No.27	Front Support
No.28	Retainer
No.29	Frame
No.30	Tap Screw

KEY NO	PARTS NAME
No.31	Thumb Bar
No.32	Retainer
No.33	Bush
No.34	Level Wind ASSY
No.35	Level Wind Pin
No.36	Washer
No.37	Nut
No.38	Pipe
No.39	Worm Shaft
No.40	Washer
No.41	Worm Pinion
No.42	Retainer
No.43	Spring
No.44	Kick Lever
No.45	Spring
No.46	Clutch Cam
No.47	Tap Screw
No.48	Clutch
No.49	Coil Spring
No.50	Pinion
No.51	Gear Side Cover ASSY
No.52	Tap Screw
No.53	O-Ring
No.54	Bearing
No.55	Washer
No.56	Washer
No.57	Tension Knob
No.58	Ball Bearing
No.59	Retainer
No.60	Bearing Plate

KEY NO	PARTS NAME
No.61	
No.62	Screw
No.63	Gear Metal
No.64	Gear
No.65	Ratchet
No.66	Washer
No.67	Drive Gear
No.68	Washer-L
No.69	Washer-D
No.70	Washer-A
No.71	Bush(Sleeve)
No.72	One Way Clutch ASSY
No.73	Ball Bearing
No.74	Washer
No.75	Leaf Spring ASSY
No.76	Spring Washer
No.77	Star Drag
No.78	Washer
No.79	Handle ASSY
No.80	Handle Nut Cap
No.81	Screw
No.82	Nut
No.83	Collar
No.84	Washer-D
No.85	O-Ring
No.86	Handle Knob Cap
①	P/SIDE COVER ASSY
②	Tension Knob ASSY
③	Handle ASSY + Knob Cap