





tailwalk

SPEAKY
2000 / 2500 HGX



KEY NO	Parts Name	KEY NO	Parts Name	KEY NO	Parts Name
1	DRAG KNOB-A	41	TAP SCREW	81	BALL BEARING
2	DRAG KNOB-B	42	TAP SCREW	82	BODY COVER ASSY
3	SCREW	43	ROTOR COVER -A	83	TAP SCREW
4	NUT	44	TAP SCREW	84	TAP SCREW
5	SPRING	45	LINK	85	WATERTIGHT WASHER
6	LEAF SPRING	46	COIL SPRING	86	HANDLE ARM ASSY
7	CAP	47	KICK LEVER	87	BUSH
8	WATERTIGHT WASHER	48	SCREW	88	HANDLE KNOB
9	PLATE	49	LOCK CAP	89	BUSH
10	SCREW	50	WATERTIGHT WASHER	90	SCREW
11	RING	51	NUT	91	HANDLE KNOB CAP
12	WASHER-D2	52	ROTOR	92	WASHER
13	WASHER-L	53	TAP SCREW	93	DRAG KNOB ASSY
14	WASHER-A	54	PLATE	94	SPOOL ASSY
15	WASHER-D1	55	WATERTIGHT WASHER	95	HANDLE ASSY
17	SPOOL	56	CAP	96	SCREW
18	PLATE	57	ROTOR BRAKE	97	BEARING PLATE
19	LINE CLIP			98	BALL BEARING
20	SPRING			100	WASHER
21	CLICK CUP	61	ONE WAY CLUTCH	SPEAKY 2500 HGX	
22	SCREW	62	SLEEVE		
23	O-RING	63	PINION		
24	BUSH	64	BALL BEARING		
25	WATERTIGHT WASHER	65	MAIN SHAFT		
26	WASHER	66	PILLAR		
27	LEAF SPRING ASSY	67	HANDLE CAP		
28	SET SCREW	68	BODY ASSY		
29	SPOOL METAL	69	O/S SLIDER		
30	RETAINER	70	O/S GEAR		
31	BAIL ASSY	71	REAR CAP	17	SPOOL
32	BUSH	72	SCREW	31	BAIL ASSY
33	LINE ROLLER	73	BALL BEARING	47	KICK LEVER
34	BALL BEARING	74	TAP SCREW	52	ROTOR
35	RING	75	O-RING	86	HANDLE ARM ASSY
36	BUSH	76	TAP SCREW	88	HANDLE KNOB
37	ARM LEVER	77	BALL BEARING	91	HANDLE KNOB CAP ASSY
38	TORX SCREW	78	DRIVE GEAR	94	SPOOL ASSY
39	TAP SCREW	79	WASHER	99	HANDLE ASSY
40	ROTOR COVER -B	80	WASHER		



KEY NO	Parts Name	KEY NO	Parts Name	KEY NO	Parts Name
1	DRAG KNOB-A	41	ROTOR COVER -B	81	HANDLE ARM ASSY
2	DRAG KNOB-B	42	TAP SCREW	82	BUSH
3	NUT	43	SCREW	83	HANDLE KNOB ASSY
4	TAP SCREW	44	LOCK CAP	84	SCREW
5	LEAF SPRING	45	WATERTIGHT WASHER	85	HANDLE KNOB CAP
6	SPRING	46	NUT		
7	PLATE	47	TAP SCREW		
8	DRAG CAP	48	CAP		
9	RETAINER	49	WATERTIGHT WASHER	89	DRAG KNOB ASSY
10	WATERTIGHT WASHER	50	PLATE	90	SPOOL ASSY
11	RING	51	O/WAY CLUTCH	91	HANDLE ASSY
12	WASHER-D	52	SLEEVE		
13	WASHER	53	SCREW		
14	WASHER-A	54	PLATE		
15	SPOOL	55	BALL BEARING		
16	PLATE	56	PINION	SPEAKY 2500S XGX	
17	LINECLIP	57	BALL BEARING		
18	SPRING	58	MAIN SHAFT		
19	CLICK CUP	59	PILLAR	15	SPOOL
20	SCREW	60	ROTOR BRAKE	29	BAIL ASSY
21	WASHER	61	HANDLE CAP	35	KICK LEVER
22	LEAF SPRING ASSY	62	BODY ASSY	39	ROTOR
23	WASHER	63	O/S SLIDER	77	BODY COVER ASSY
24	TAP SCREW	64	SCREW	86	HANDLE ARM ASSY
25	ROTOR COVER -A	65	WASHER	87	HANDLE KNOB ASSY
26	TAP SCREW	66	O/S GEAR	90	SPOOL ASSY
27	ARM LEVER	67	BALL BEARING	92	HANDLE ASSY
28	TORX SCREW	68	TAP SCREW		
29	BAIL ASSY	69	REAR CAP		
30	BUSH	70	TAP SCREW		
31	LINE ROLLER	71	BALL BEARING		
32	BALL BEARING	72	DRIVE GEAR		
33	RING	73	BALL BEARING		
34	BUSH	74	WASHER		
35	KICK LEVER	75	WASHER		
36	LINK	76	WASHER		
37	COIL SPRING	77	BODY COVER ASSY		
38	WASHER	78	TAP SCREW		
39	ROTOR	79	TAP SCREW		
40	TAP SCREW	80	WATERTIGHT WASHER		