


KEY NO	PARTS NAME
No.1	Tension Knob
No.2	Washer
No.3	Washer
No.4	Washer
No.5	O-Ring
No.6	Thumb Screw
No.7	Washer
No.8	Gear Side Cover ASSY(O/W Clutch)
No.9	Coil Spring
No.10	Ball Bearing
No.11	Ring
No.12	Pinion
No.13	Clutch
No.14	Screw
No.15	Cam Plat
No.16	Clutch Cam
No.17	Kick Lever
No.18	Spring
No.19	Spring
No.20	Stopper ASSY
No.21	Screw
No.22	Screw
No.23	Level Wind ASSY
No.24	Bush
No.25	Washer
No.26	Retainer
No.27	Level Wind Pin
No.28	Washer
No.29	Level Wind Nut
No.30	
No.31	Pipe
No.32	Bush
No.33	Washer
No.34	Retainer
No.35	Worm Shaft ASSY

KEY NO	PARTS NAME
No.36	Coil Spring
No.37	Front Support
No.38	Screw
No.39	Pillar
No.40	Frame ASSY
No.41	Clutch Link
No.42	Thumb Bar
No.43	Tap Screw
No.44	Spool Unit
No.45	Retainer
No.46	Ball Bearing
No.47	Spool Pinion
No.48	Retainer
No.49	Washer
No.50	Screw
No.51	Spool Cover ASSY
No.52	Collar
No.53	Gear
No.54	Washer
No.55	Tap Screw
No.56	Click Leaf Spring
No.57	Screw
No.58	Palm Side Cover
No.59	Retainer
No.60	Washer
No.61	Click Claw
No.62	Washer
No.63	Click Lever
No.64	Retainer
No.65	Ball Bearing
No.66	Bearing Plate
No.67	Screw
No.68	Gear Metal
No.69	Ratchet
No.70	Washer

KEY NO	PARTS NAME
No.71	Drive Gear
No.72	Washer-L
No.73	Washer-D
No.74	Washer-A
No.75	Washer-D
No.76	Sleeve
No.77	Washer
No.78	Leaf Spring ASSY
No.79	Spring Washer
No.80	Du-Washer
No.81	Star Drag ASSY
No.82	Washer
No.83	Handle Arm ASSY
No.84	Washer
No.85	Handle Knob ASSY
No.86	Screw
No.87	Handle Knob Cap
No.88	Nut
No.89	Retainer
No.90	Screw
No.91	Coil Spring
No.92	Click Pin
No.93	Click Plate
No.94	Retainer
No.95	Ring
No.96	Control Plate
No.97	Plate
No.98	Screw
No.99	Washer
No.100	① Handle ASSY
No.101	Bush
No.102	② Tension Knob ASSY
No.103	③ Palm Side Cover ASSY
No.104	④ Spool ASSY (2 Ball Bearing)
No.105	Screw



KEY NO	PARTS NAME
No.1	Tension Knob
No.2	Washer
No.3	Washer
No.4	Washer
No.5	O-Ring
No.6	Thumb Screw
No.7	Washer
No.8	Gear Side Cover ASSY (O/W Clutch)
No.9	Coil Spring
No.10	Ball Bearing
No.11	Ring
No.12	Pinion
No.13	Clutch
No.14	Screw
No.15	Cam Plat
No.16	Clutch Cam
No.17	Kick Lever
No.18	Spring
No.19	Spring
No.20	Stopper ASSY
No.21	Screw
No.22	Screw
No.23	Level Wind ASSY
No.24	Bush
No.25	Washer
No.26	Retainer
No.27	Level Wind Pin
No.28	Washer
No.29	Level Wind Nut
No.30	
No.31	Pipe
No.32	Bush
No.33	Washer
No.34	Retainer
No.35	Worm Shaft ASSY

KEY NO	PARTS NAME
No.36	Coil Spring
No.37	Front Support
No.38	Screw
No.39	Pillar
No.40	Frame ASSY
No.41	Clutch Link
No.42	Thumb Bar
No.43	Tap Screw
No.44	Spool Unit
No.45	Retainer
No.46	Ball Bearing
No.47	Spool Pinion
No.48	Retainer
No.49	Washer
No.50	Screw
No.51	Spool Cover ASSY
No.52	Collar
No.53	Gear
No.54	Washer
No.55	Tap Screw
No.56	Click Leaf Spring
No.57	Screw
No.58	Palm Side Cover
No.59	Retainer
No.60	Washer
No.61	Click Claw
No.62	Washer
No.63	Click Lever
No.64	Retainer
No.65	Ball Bearing
No.66	Bearing Plate
No.67	Screw
No.68	Gear Metal
No.69	Ratchet
No.70	Washer

KEY NO	PARTS NAME
No.71	Drive Gear
No.72	Washer-L
No.73	Washer-D
No.74	Washer-A
No.75	Washer-D
No.76	Sleeve
No.77	Washer
No.78	Leaf Spring ASSY
No.79	Spring Washer
No.80	Du-Washer
No.81	Star Drag ASSY
No.82	Washer
No.83	Handle Arm ASSY
No.84	Washer
No.85	Handle Knob ASSY
No.86	Screw
No.87	Handle Knob Cap
No.88	Nut
No.89	Retainer
No.90	Screw
No.91	Coil Spring
No.92	Click Pin
No.93	Click Plate
No.94	Retainer
No.95	Ring
No.96	Control Plate
No.97	Plate
No.98	Screw
No.99	Washer
No.100	① Handle ASSY
No.101	Bush
No.102	② Tension Knob ASSY
No.103	③ Palm Side Cover ASSY
No.104	④ Spool ASSY (2 Ball Bearing)
No.105	Screw