



KEY NO	Parts Name	KEY NO	Parts Name	KEY NO	Parts Name
1	DRAG KNOB ASSEMBLY	25	BAIL HOLDER	49	REAR COVER
2	WASHER RETAINING RING	26	SCREW	50	SCREW
3	KEY WASHER	27	BAIL ARM	51	HANDLE CAP
4	DRAG WASHER	28	LINE ROLLER COLLAR	52	RUBBER
5	EARED WASHER	29	BALL BEARING	53	SCREW
6	SPOOL	30	LINE ROLLER	54	BODY DECORATION PLATE
7	SPRING	31	LINE ROLLER WASHER	55	MAIN GEAR
8	SCREW	32	BAIL ASSEMBLY	56	WASHER
9	RETAINER PLATE	33	KICK LEVER	57	BODY COVER
10	CLICK GEAR	34	ARM LEVER SHAFT	58	SCREW
11	SCREW	35	COMPRESSING SPRING	59	SCREW
12	SPOOL ADJUST WASHER	36	ARM LEVER CAP	60	WASHER
13	METAL WASHER	37	SCREW	61	BALL BEARING
14	SLEEVE	38	SCREW	62	OSCILLATION GEAR
15	SPOOL HOLDER	39	BAIL BEARING RETAINER	63	SCREW
16	CLICK WHEEL	40	BODY HEAD COVER	64	BUSHING
17	MAIN SHAFT	41	BALL BEARING	65	HANDLE KNOB SLEEVE
18	ROTOR NUT	42	BALL BEARING HOLDER	66	SCREW
19	SCREW	43	ONE WAY CLUTCH ASSEMBLY	67	HANDLE KNOB
20	RETAINER	44	PINION GEAR	68	HANDLE KNOB CAP
21	ROTOR DECORATE RING	45	BODY	69	HANDLE SET
22	ROTOR	46	SLIDER GUIDE BAR	70	TOTAL HANDLE SET
23	SCREW	47	SLIDER	71	SPOOL ASSEMBLY
24	SCREW CAP	48	SCREW	72	HANDLE CAP ASSEMBLY